

# Johnson & Evinrude årsmodell forklaring.



Tabell for årsmodell koder

I	N	T	R	O	D	U	C	E	S
1	2	3	4	5	6	7	8	9	0

**C J 10 T L 4 EC A**

Det er bokstavene i modellkoden som er merket med "rødt" i eksempelet over som forteller hvilken årsmodell motoren er.

I dette eksempelet: E=9, C=8 . Dvs. årsmodell 1998.

Eksempler på årsmodellkoder			
1979 - UE	1980 - CS	1981 - CI	1982 - CN
1983 - CT	1984 - CR	1985 - CO	1986 - CD
1987 - CU	1988 - CC	1989 - CE	1990 - ES
1991 - EI	1992 - EN	1993 - ET	1994 - ER
1995 - EO	1996 - ED	1997 - EU	1998 - EC
1999 - EE	2000 - SS	2001 - SI	2002 - SN
2003 - ST	2004 - SR	2005 - SO	2006 - SD

Første bokstav i modellbetegnelse	Produksjonsland/Markedsland
A	Australia
B	Belgia

C	Canada
H	Hong Kong
S	Sør Afrika
T	Tracker Modell
V	Båtbygger

Hvis bokstaven i tabellen over mangler er motoren produsert I USA.

Andre bokstav i modellbetegnelse	Motormerke
J	Johnson
E	Evinrude
	Komersiell (Yrkes/arbeidsmotor)
V	Quiet rider ®

Siffer	Hestekrefter
--------	--------------

Eks. 10=10hk, 150=150hk.

Bokstaver etter siffer	Type motor/Utstyrsnivå/Beregnet marked.
AE	Electric Start - Alaska
AR	Rope Start - Alaska
BA	AC Lighting - Rope Start
BE	Belgium Derated - Electric Start
BF	Belgium Derated - Rope Start
BG	Belgium Derated - Rope Start
BI	Belgium Derated - Rope Start
BR	Euro Rope Start
C	Counter-Rotation
CE	Canada Derated - Electric Start
CR	Canada Derated - Rope Start
D	Remote Electric
DE	Derated - Electric Start
DR	Derated - Rope Start
DT	Derated - Electric Start / Trim & Tilt
E	Electric Start

ER	Electric Start - Sport Styling
ES	Electric Start - Special
FA	4-Stroke, Rope Start - AC Lightning
FE	4-Stroke, Electric Start / Tiller
FP	Commercial with Program Tilt
FR	4-Stroke, Rope Start
FRE	4-Stroke, Electric Start / Remote
FS	<i>FICHT</i> <sup>™</sup> , Trim & Tilt
FT	<i>FICHT</i> <sup>™</sup> , Trim & Tilt / Special Styling
G	Special Styling
H	Less Integral Tank / Hydraulic Steering
I	<i>FICHT</i> Fuel Injection
IE	Italy Electric Start
IK	Italy Electric Start
J	Jet Drive
K	3-Cylinder 25/35
KC	Kerosene Rope Start
KG	Kerosene / Gasoline
KS	Kerosene Rope Start
M	Manual Tilt - Electric Start
MS	Manual Tilt - Electric Start / Special
N	Counter-Rotation
P	Power Steering
Q	3-Cylinder 25/35 Trim & Tilt
R	Rope Start
RA	Australia Rope Start
RC	Rope Start - Commercial / CD Ignition
RD	Rope Start - Deluxe
RE	Remote Electric
RP	Commercial with Program Tilt
RS	Rope Start - Commercial
RW	Commercial with Interlock
S	Sail - Special Styling
SC	Special Styling / Counter-Rotation
SE	Electric Start Non-Tilt Sail
SI	Italy Special Derated

SL	60°V, Trim & Tilt
SP	Special Styling
SR	Rope Start - Sail - Non-Tilt
ST	Special Styling - Trim & Tilt
T	Trim & Tilt - Electric Start
TE	Tiller Electric
TR	Trim & Tilt - Sport Styling
TT	Tiller - Trim & Tilt (Backtroller)
U	Manual Tilt
V	Special Gearcase
W	110° Angle Drive - Rope Start
WM	Electric Commercial - Manual Tilt
WMP	Same as "WM" w/Chrome Pump
WT	Electric Commercial - Trim & Tilt
WTP	Same as "WT" w/Chrome Pump

Neste bokstav	Stamme lengde
	15 in
L	20 in
Y	22.5 in
X	25 in
Z	30 in

Siffer etter stammelende	2-takt eller 4-takt
Uten siffer	2-takt
Siffer 4	4-takt

Bokstavkode merket "rødt" i eksempel	Årsmodell (se tabell over)
--------------------------------------	----------------------------

Evt. bokstav etter årsmodellkode	Modellvariasjoner (ikke vesentlig)
----------------------------------	------------------------------------

